

Pairing-Vorgang

Schalten Sie die Kamera aus. Schliessen Sie das Kamerakabel an die Kamera (oder Gerät mit LANC) an. Schliessen Sie den Empfänger an das andere Ende des Kamerakabels an und drücken Sie die rote Taste am Empfänger, während Sie gleichzeitig die Kamera einschalten, bis die Anzeige am Empfänger blinkt. Dann lassen Sie die Taste am Empfänger los.

Drücken Sie dann lange die Taste am Sender. Die Anzeigen am Sender und am Empfänger blinken und gehen dann aus. Dies zeigt an, dass das Pairing abgeschlossen ist. Dann erst lassen Sie die Taste am Sender los.

Ein Sender kann mit mehreren Empfängern LANC-02-R auf die gleiche Art gepaart werden.

Pairing Procedure

Switch off the camera. Connect the camera cable to the camera (or device with LANC). Connect the receiver to the other end of the camera cable and press the red button on the receiver while simultaneously switching on the camera until the indicator on the receiver flashes. Then release the button on the receiver.

Then press and hold the button on the transmitter. The indicators on the transmitter and receiver flash and then go out. This indicates that pairing is complete. Only then release the button on the transmitter.

A transmitter can be paired with several receivers LANC-02-R in the same way.