







**Lanparte
v mount plate**

**LPT-VMP-01
USER MANUAL**



Lanparte v-mount plate
VMP-01





Dimension of
VMP-01


Weight: 880g

V lock underneath


With the V lock, the VMP-01 can be easily attached to the VCT-14 plate




Rods height adjustment function





Rotate the knob to
adjust the height



Highest position





Lowest position




Rotate the knob to
adjust the height

Dimensions of the camera plate.



This is a standard quick release plate from Lanparte, and can be used on the VMP-01, VMS-01 and BP-02 units.

How to use the safety lock system





Hold the trigger and push the bar in the direction of the arrow.




Warning: When you operate the camera, please switch it to the "locked" status.

Two methods to release the camera plate






The VMP-01 fits the
15mm rail system




Any 15mm rail accessories
can be mounted on the VMP-01

Rod extension function


Normal



Screw the screws inside



Extended



HongKong Lanparte Technology Limited

Tel :+86-769-81888368

Fax :+86-769-85841828

Email:info@lanparte.com

Add :39#, xin'an 2nd Road Chang'an Town
Dongguan City Guangdong China(PRC)

<http://www.lanparte.com>

Hotline:+86-400-602-6822