

LanParte Camera Battery Adapter Compatibility

Lanparte Kamera-Akku-Adapter Kompatibilität

	Original Battery	Battery Adapter	Compatible Cameras *)
	Canon LP-E6 LP-E6N	E6P-01	Canon EOS 5D2, 5D3, 5D4, 5DSR, 60D, 70D, 80D, 6D, 6D2, 7D, 7D2, R
		E6P-D D-tap connector	
	Canon LP-E8	E8P-01	Canon EOS 550D, EOS 600D, EOS 650, EOS 700D
	Canon LP-E17	LP-E17	Canon EOS M3, M5, M6, 760D, 750D, 800D, 77D, 200D, RP
	Sony NP-FW50	FW-50P	Sony A7R, A7, A33, A35, A37, A55, A7S, A7S2, A7R2, A7M2, A5000, A5100, A6000, A6300, A6500, NEXT-5T, 5R, 3N
		FW-50P-D D-tap connector	
	Sony NP-FZ100	FZ-100P	Sony A9, A7 III, A7R III, A7R IV
		FZ-100P-D D-tap connector	

LanParte Camera Battery Adapter Compatibility

Lanparte Kamera-Akku-Adapter Kompatibilität

	Original Battery	Battery Adapter	Compatible Cameras *)
	Panasonic DMW-BLF19GK	BLF19P-01	Panasonic GH3, GH4, GH5
		BLF19P-D D-tap connector	
	Nikon EN-EL15 EN-EL15b	EL15P-01	Nikon D6000, D7000, D7100, D7200, D800, D800E, D810, D850, D750, D610, D600, D500, V1, Z6, Z7
	Nikon EN-EL14	EP-5A	Nikon D3100, D3200, D3300, D3400, D5100, D5200, D5300, D5500, D5600, P7000, P7100, P7700, P7800

*) ... and newer cameras using the original battery (column 2).

*) ... und neuere Kameras, welche den Original-Akku (Spalte 2) verwenden.