
# PLUTO Troubleshooting

- APP not connecting to PLUTO
- Camera does not fire
- IR Remote Function not working
- PLUTO Valve not working


## PLUTO Fehlerbehebung

- APP stellt keine Verbindung zu PLUTO her
- Kamera löst nicht aus
- IR-Funktion funktioniert nicht
- PLUTO-Ventil funktioniert nicht


### Test 1: The app does not connect to the trigger



#### Test 2: The trigger does not fire the camera



#### Test 3: IR remote function does not work



## Test 4: The Pluto Valve does not work

